

Installation Instructions

BED-BAR Model # 1200B

The BED-BAR simply slides over the bed frame.

1. Note the thickness of your side rail. Most wooden side rails are $\frac{3}{4}$ " or 1" thick.
2. For side rails that are $\frac{3}{4}$ " thick place the rubber shim between the BED-BAR and the side rail of the bed.
3. Slide the BED-BAR over the side rail.
4. Secure the BED-BAR to the [headboard](#) or use the [support rail](#) accessory if you do not have a headboard.

