

Installation Instructions

BED-BAR Model # 1200C

The BED-BAR simply slides over the bed frame.

1. Remove or lift the mattress and box spring from the angle iron bed frame.
2. Slide the BED-BAR over the bed frame.
3. Secure the BED-BAR to the [headboard](#) or use the [support rail](#) accessory if you do not have a headboard.

